

Hiretech Spare Parts List

072	911662	Lead Motor Assembly
073	168104	Sleeve
074	980621	Washer
075	902550	Bearing
076	962407	Screw
077	168324	Spring Brush
078	167302	Ring Retaining
079	167208	Retainer Brush Block
* 080	163104	Field Coil 110/120 Volt HT8
080	163112	Field Coil 220/240 Volt HT8
081	166172	Baffle Motor
082	167204	Retainer Baffle
083	160408	Armature 110/120 Volt
083	160412	Armature 220/240 Volt
084	915028	Key
085	980004	Spacer
086	163008	Fan
087	167802	Shield Pulley
088	962109	Screw
089	162023	Clamp Fan (DISCONTINUED)
090	962345	Screw
091	168212	Spacer Motor Pulley
092	163304	Flange Pulley
093	166909	Pulley Motor
094	166906	Pulley Fan
095	980648	Washer
096	980626	Washer Lock
097	920132	Nut
098	167704	Shaft Fan
099	163004	Fan Intake
100	008212	Spacer Fan
101	010210	Screw
102	167210	Retainer Seal
103	167608	Seal Fan
104	162021	Clamp Bearing
105	902567	Bearing (Fan & Floor Roller)
106	168203	Spacer Fan Bearing
107	164202	Housing Fan
108	167312	Ring Retaining
109	980699	Washer (DISCONTINUED)

Hiretech Spare Parts List

110	962411	Screw
111	162006	Clamp Bearing
112	902550	Bearing Drum Shaft
113	161108	Bush Bearing
114	168206	Spacer Baering
115	925113	Pin Drum Shaft
116	162532	Drum Assembly Complete
116	167716	Shaft Drum
117	915028	Key
119	162312	Drum Cover Kit
120	164607	Insert Drum Kit
121	163668	Lifting Pin Assembly
122	020045	Clamp Bar Paper (reversible)
123	000920	Screw Clamp Bar (screwdriver slot)
123	163657	Screw Clamp Bar (coin slot)
124	168209	Spacer Bearing
125	162023	Clamp Fan (DISCONTINUED)
126	962345	Screw
127	166916	Pulley Drum
128	980648	Washer
129	980626	Washer
130	920132	Nut
131	903260	"Belt Drive 3/4" (19mm) Wide"
132	903273	"Belt Fan 1/2" (13mm) Wide"
133	163012	Assembly Intake Fan
134	163789	Brush Block Assembly
135	101219	Floor Roller Assembly
136	163823	Retainer Dust Bag Disposable
138	07037	Disposable Paper Dust Bag HT8 Pack 2
138	07039	Disposable Paper Dust Bag HT8