
Clarke American Sanders Clarke



CP/ 2.2

INSTRUCTIONS FOR USE

PART III

GENERAL INSTRUCTION FOR USE

Numbered sections below correspond to numbered photos

1. General overview of equipment:

Accessories shown in the illustrations may vary from model to model.

7. Cord set:

This vacuum cleaner is equipped with a 50 ft extension power cord, of type 3x16AWG, 125V, SJT, SJO, that must be connected to the cord set from the machine. Always use and connect such an extension cord to this vacuum cleaner. Place the end of the extension cord in to the snap hook from the vacuum cleaner in order to create a cord relieve by the hook. When cleaning is performed roll up the extension cord starting at the machine end and store it at the machine belt by snapping the nylon strap around the cord.

8. Cord Relief:

Connect the extension cord to the outlet from the cleaner. Place the end of the extension cord in to the snap hook that is placed at the vacuum cleaner in order to create a Cord Relief by the hook. Make sure the cord is properly secured in the hook.

9. On/Off:

The on/off switch is located in a separate housing attached to the right side of the waistbelt. Tilt the switch for ON or OFF function.

7 CORD SET



7:1



7:2

8 CORD RELIEF







8:2



9 ON/OFF



9:1 OPERATION

